

# Care Instruction for oiled surfaces



## Maintenance and care of oiled surfaces



### Regular damp mopping

With the *Ecoline Wash Care* normal dirt can be removed mildly, thoroughly and streak-free from all washable surfaces.

Dilute *Ecoline Wash Care* concentrate with water (approx. 3 caps per 5 liter water). Make sure that the wiping cloth is wrung out carefully to ensure damp cleaning. Wipe dry if necessary.

**Perfect combination:**  
*Ecoline Maintenance-Set* and  
*Ecoline Wash Care*

**Frequency of use:**  
Weekly (in objects) or whenever needed



### Refreshing care & maintenance

Always use *Ecoline Wash Care* before applying *Wax Care*.

For an effortless spot removal and refreshing of all oiled wood surfaces just pour one cup of *Wax Care* (for approx. 1-2 m<sup>2</sup> on the surface and rub in evenly with a cloth. No visible overlay marks to non-treated surface visible.

**Important:**  
Never use a sharp fibre mop or scrubbing detergents. Those can harm your surface.

**Frequency of use:**  
Monthly (in objects), 2 x per year  
or whenever needed



### Intensive cleaning

*Ecoline Magic Cleaner* cleans fast and intensive all dirty surfaces.

Dilute 1:10 with water and spread evenly either with a cloth or mop. Allow to absorb for 5 – 20 minutes. The loosened dirt can be collected with either cloth or mop.

Then damp mop 2 – 3 times with clear water until it is clean. Wipe dry. After complete drying, maintain with *Ecoline Wax Care*.

**Frequency of use:**  
2 times per year (in objects)  
or whenever needed

### Basic rules apply for all wood floors:

- The wood floor should be dry-cleaned on a regular basis. Refrain from using microfiber and use a parquet nozzle while vacuum cleaning in order to avoid scratch marks.
- For a healthy indoor climate and for the conservation of value we recommend a room temperature of 20 – 25 °C as well as an air humidity of 55 – 60%.
- Pay attention that chairs with bottom rollers are suitable for parquet. Protect the floor with mats. Put felt pads under the chair leg in order to avoid scratch marks.
- We recommend dirt traps, e.g. door scrapers or carpet areas at the entrance as sharp-edged dirt like sand can damage every floor.
- Protect your wood floor from water (e.g. wetness due to leaking flower pots or vases).
- Refrain from using objects that bottom side is either made of rubber or latex (e.g. door stopper). The containing substances (softening agents) may cause dirt spots.

You will realize that your treated and maintained floor will become low-maintenance over time.